

# Battery Disconnects



## Low Current Battery Switches

| Littelfuse Part # | Description                                       |
|-------------------|---|
| 08098700          | 100A Battery Disconnect - Removable Handle        |
| 08099080          | 150A Battery Disconnect - Removable Handle w/Boot |

## Push-to-Off Switch

| Littelfuse Part # | Description                           |
|-------------------|---------------------------------------|
| 08098400          | 250A Battery Disconnect - Push Button |

## 310A M-750 Battery Selector Switch

| Littelfuse Part # | Description                  |
|-------------------|------------------------------|
| M-750             | 310A Battery Selector Switch |

## 300A SR Series Switches

| Littelfuse Part # | Description  |
|-------------------|--|
| 880062            | 300A Master Battery Disconnect - Panel Mount           |
| 880064            | 300A Master Battery Disconnect Surface Mount w/Lockout |

## 300A 75920 Series Switches

| Littelfuse Part # | Description   |
|-------------------|---|
| 75920             | 300A Master Battery Disconnect Panel Mount w/Lockout      |
| 75920-01          | Master Disconnect Panel Mount w/Lockout and Yellow Handle |

## 500A Dual-Pole TR Series Switches

| Littelfuse Part # | Description  |
|-------------------|--|
| 880175            | 500A Dual Pole Master Battery Disconnect Panel Mount w/Lockout                   |
| 880175-0001       | 500A Dual Pole Master Battery Disconnect Panel Mount w/Lockout and Red Handle    |
| 880175-0002       | 500A Dual Pole Master Battery Disconnect Panel Mount w/Lockout and Yellow Handle |

## Metal Body Switches

| Littelfuse Part # | Description                         |
|-------------------|-------------------------------------|
| 2484              | 175A Battery Disconnect - Lever     |
| 75908             | 300A Battery Disconnect - Lever     |
| 75907             | 300A Double Pole Battery Disconnect |