

PGB, PGA, PGG

| REMOTE INDICATION | | |
|---|--|---|
| Product | Features | Accessory For |
| <p>PGB-0302 Remote Indication and Reset Assembly</p>  | Panel-mounted remote indication and reset, standard 22 mm mounting with NEMA 4 and NEMA 13 rating. | PGR-5325 |
| <p>PGB-0325 Remote Indication and Reset Assembly</p>  | Panel-mounted remote indication and reset with NEMA 1 rating. | PGR-5325 |
| <p>PGA-0500 Analog % Current Meter</p>  | Panel-mounted analog am meter displays the Ground-Fault Current as a percentage of the set-point. | PGR-4300 PGR-5701 PGR-6100 |
| <p>PGA-0510 Analog Ohm Meter</p>  | Panel-mounted analog ohmmeter displays the Insulation Resistance from 0 Ω to infinity. | PGR-3200 PGR-6100 PGR-8600 |

| GROUND-REFERENCE MODULES | | |
|--|---|-----------------|
| Product | Features | Accessory For |
| <p>PGG-0024 Ground Reference Module</p>  | Connects the PGR-2601 relay to an ungrounded 24 Vdc bus. | PGR-2601 |
| <p>PGG-0048 Ground Reference Module</p>  | Connects the PGR-2601 relay to an ungrounded 48 Vdc bus. | PGR-2601 |
| <p>PGG-0125 Ground Reference Module</p>  | Connects the PGR-2601 relay to an ungrounded 125 Vdc bus. | PGR-2601 |
| <p>PGG-0250 Ground Reference Module</p>  | Connects the PGR-2601 relay to an ungrounded 250 Vdc bus. | PGR-2601 |
| <p>PGG-0500 Ground Reference Module</p>  | Connects the PGR-2601 relay to an ungrounded 500 Vdc bus. | PGR-2601 |
| <p>PGG-0780 Ground Reference Module</p>  | Connects the PGR-2601 relay to an ungrounded 780 Vdc bus. | PGR-2601 |

Note: Contact factory for other voltages.